STOR-X™

Closet CAD

## Manual / Training Guide

StorXCad

Lesson 2: Setup & File Management
New Job, Customer Details, Auto Closet Setup, Save/Name Job, Naming the Closet

To install the program on your computer please refer to the **installation guide** available at **http://www.closetcad.net/storxcad/help**

by **3D** CADSOFT

Choose 'Open Existing Job' to open an old existing file. The directory will be defaulted to where your last file has been saved. If this is the first time you are using the program, the default directory will be the quotes folder in your installation directory, which is located at **C:\Program Files\3dcadsoft\StorXCad\quotes**.

Choose 'New Job' to start designing.

STOR-X

When you create a new design, the **Customer Details** dialog will be shown to enter the **customer details** (such as Name, Address, Contact details, etc) and the job information (Job name, Manufactory No., Designer name, Design Date, etc).

You can choose 'Cancel' to skip the dialog.

The customer details can be edited later by using the Customer Details Icon in Plan View.

STOR-X

Hit 'OK' to exit Customer Details and this dialog will appear:

The **Room Layout Wizard** can be used for all reach in closets and rectangular spaces of any size.

Start with the left front wall and enter the desired values.

You can use the '**Tab**' key to advance from field to field; it will take you around the space clockwise, then through the Top Shelf, Ceiling Height and Base Molding dimensions.

Top Shelf, Ceiling Height and Base Molding dimensions can be edited later if needed by using the Global Settings Icon that shows in Plan View.

Global Settings

Hit 'Auto' to be taken to the first Plan View


Room Layout Wizard

This is a basic Plan View.
It shows the wall dimensions you set up and the green zone shows the three dimensional space you can build in.

Select the '**Save As**' icon to bring up the standard 'Save As' dialog

Once the system detected a file with the same name of the one you entered in the target directory, it will give you the option to overwrite it or not.

Once the file you are working on got the name, this name will be listed on the top left hand corner.

The **Job Manager** allows you to edit the closet details.

This dialog can be used to print and email various documents related to the current job.
Turn on the checks under each column for the project file you want to print or email.
The prefix **e-** stands for e-mail and **p-** for print.

'**BOM Revisions**' will show all the BOM versions stored in this job.

Click '**View Closet**' to take you back to the plan view.

Multiple closets or different closet versions in the same job can be added simply by using the '**Add New Closet**' and '**Copy Closet**' buttons.

In the Closet Properties dialog you can change closet **name** and **type**.
Both are just descriptive details and they do not alter the job itself.

Double click on the closet you want to choose and a Closet Properties dialog will be shown.

The closet name that you have just entered will be displayed on the upper left corner.